

2018 SmartWay Shipper Partner Tool: User Guide U.S. Version 2.0.17 (Data Year 2017)







2018 SmartWay Shipper Partner Tool: User Guide U.S. Version 2.0.17 (Data Year 2017)

Transportation and Climate Division Office of Transportation and Air Quality U.S. Environmental Protection Agency



Office of Transportation and Air Quality EPA-420-B-18-047 October 2018

Table of Contents

INTRODUCTION	5
What Is The SmartWay Transport Partnership?	5
Why Do Shippers Join The SmartWay Transport Partnership?	5
How Do Shippers Join The SmartWay Transport Partnership?	6
How Do I Join If My Parent Company Has Multiple Subsidiaries?	6
What Data Do I Need To Gather To Complete The Shipper Tool?	7
What Software & Hardware Is Required For Completing The Shipper Tool?	8
How do I set the Security Level When Opening SmartWay Tools?	9
What Is Included In The SmartWay Shipper Company Partnership Agreement?	11
Step 1—Data Collection Requirements	13
Introductory Screens	13
Auto-Population	13
Data Requirements For Establishing Your Data Collection Year	13
Data Requirements For Section 1: Specify Official Partner Name	14
Data Requirements For Section 2: Enter Contact Information	14
Data Requirements For Section 3: Company Description	15
Data Requirements For Section 5: Participation Level and Data Input Method	16
Data Requirements For Section 6: Data Entry	16
Step 2—Data Entry	22
Downloading The SmartWay Shipper Tool	22
Entering Partner Name	22
Entering Contact Information	22
Completing The Company Description Screen	24
Downloading the Latest SmartWay Carrier Data File	24
Selecting a participation Level	25
Selecting the Data Input Method	26
Selecting A Company For Data Entry	26
Inputting Carriers for a Company	27
Completing The Manual Input SmartWay Carriers Screen	28
Completing The Manual Input Non-SmartWay Carriers Screen	28
Completing The Carrier Subdivision Screen	29

Completing The Activity Data Screen	30
Completing the % SmartWay Screen	31
Completing the Mile & Weight Improvements Screen	32
Completing the Modal Shift Impacts Screen	33
Reviewing Your Results	34
Submitting Your Tool To EPA	35
Step 3 – Additional SmartWay Resources	37
APPENDIX: WORKSHEETS FOR DATA COLLECTION	38
Worksheet #1: Contact Information	38
Worksheet #2: Shipper Company Characterization	40
Worksheet #3A: Select Carrier(s) (page 1 of 2)	41
Worksheet #3A: Select Carrier(s) (page 2 of 2)	42
Worksheet #3B: Activity Data (page 1 of 2)	43
Worksheet #3B: Enter Activity Data (page 2 of 2)	44
Worksheet #4: Enter % SmartWay Allocation Data	45
Worksheet #5: Enter Mile & Weight Improvements Data	46
Worksheet #6: Enter Modal Shift Impacts Data	47

INTRODUCTION

WHAT IS THE SMARTWAY TRANSPORT PARTNERSHIP?

Launched in 2003, the SmartWay Transport Partnership is a public/private collaboration between the EPA and the freight industry to improve fuel efficiency, increase environmental performance, and encourage supply chain sustainability.

Seven types of freight transport companies can join SmartWay.

- Freight shippers
- Logistics companies (including 3PLs/4PLs¹)
- Truck carriers
- Rail carriers
- Barge carriers
- Multimodal carriers
- Air carriers

Companies join the SmartWay Transport Partnership by submitting a Partner Tool to SmartWay. The SmartWay Tools (1) assess freight operations; (2) calculate fuel consumption and carbon footprints; and (3) track fuel-efficiency and emission reductions. SmartWay Tools must be submitted each year for the company to remain a Partner in good standing. Tools submitted and approved on time qualify partners to use the SmartWay Logo.

SmartWay ranks Partners' efficiency and environmental performance and recognizes superior performance through the SmartWay Excellence Awards.

WHY DO SHIPPERS JOIN THE SMARTWAY TRANSPORT PARTNERSHIP?

The SmartWay Transport Partnership provides shipper companies with ways to reduce the environmental impact of their freight operations and address costs. Designed <u>with and for</u> the freight sector, the SmartWay Transport Partnership delivers solutions to marketplace needs and challenges. With access to the latest in EPA-tested technologies and peer-provided success stories, carriers that join the SmartWay Transport Partnership can gain a better understanding of their environmental footprint and assert their corporate leadership.

Additionally, SmartWay Partners are associated with an internationally recognized and respected brand that symbolizes cleaner, more efficient transportation choices.

Shipper companies that join SmartWay move significant amounts of freight with SmartWay Carriers. The higher efficiency of carriers in SmartWay compared to non-SmartWay carriers gives SmartWay shipper companies an opportunity to improve corporate freight efficiency, reduce their carbon footprint, and

¹ 3PLs/4PLs Third party logistics/fourth-party logistics companies

voluntarily advance freight sustainability for themselves and their customers.

Participation in SmartWay helps SmartWay Shipper Partners

- identify opportunities to improve efficiency,
- demonstrate efficiency to customers and stakeholders,
- evaluate and compare carrier performance, and
- determine the company's transportation carbon footprint.

SmartWay provides shippers with free tools that help assess and compare various freight transportation options with detailed reports and analyses that support better business decision making.

How Do Shippers Join The SmartWay Transport Partnership?

Shipper companies join SmartWay by submitting a SmartWay Shipper Tool (hereafter known as the "Shipper Tool," or simply, the "Tool.")

Shipper companies that submit tools that are approved by EPA are known as "SmartWay Shipper Company Partners."

When a shipper company submits a Shipper Tool to EPA, they agree to the requirements stipulated in the SmartWay Shipper Partnership Agreement--notably, that they will measure and report the emissions performance of their company <u>annually</u> and provide supporting documentation to EPA upon request.

All SmartWay Shipper Partners agree to complete and submit the SmartWay Shipper Tool to

- define company composition,
- characterize company activity,
- individually benchmark multiple companies, and
- track annual changes in performance.

Upon approval of a Shipper Tool submission, a shipper company will be identified as SmartWay Shipper Partner on EPA's website, on the SmartWay Partner List, and in a database used to identify companies that meet SmartWay's annual requirements. On-time submission and approval of the Tool also qualifies Shipper Partners for use of the SmartWay Logo. The carrier will also receive information on how to access its current SmartWay registration document and other information through the Partner Portal.

How Do I Join IF My PARENT COMPANY HAS MULTIPLE SUBSIDIARIES?

Shippers with subsidiaries may submit a single tool for their parent company and all of its subsidiaries. If a shipper chooses to do this, the entire organization will be considered a SmartWay Partner and the performance rating will be assigned to the entire organization. The partner will be listed on the SmartWay website under the parent company's name.

Individual subsidiaries may join as separate partners if the parent company wishes to have them listed

individually on the SmartWay website. Each subsidiary would submit a separate tool.

SmartWay highly recommends developing your list of subsidiary companies beforehand by using an organization chart or perhaps a customer interface web page. For example, evaluate how your organization contracts with carriers, identify your companies' different NAICS codes, and determine how they choose what carriers to hire.

The best strategy is to have a clear idea of how to define your companies before filling out the tool.

WHAT DATA DO I NEED TO GATHER TO COMPLETE THE SHIPPER TOOL?

To participate in SmartWay, shippers need to gather the following essential information to complete the Shipper Tool:

- The official company name to be used on the SmartWay website for public recognition of participation in SmartWay;
- Company contact information:
 - Contact details for your Working Contact'
 - Contact details for an Executive Contact (cannot be the same as the working contact)'
 - Contact details for your Sustainability Contact and Other contacts (optional)'
- SmartWay ID number (if this is not your first tool submission);
- North American Industry Classification System (NAICS) codes for the company;
- The level at which the shipper chooses to participate in SmartWay; and
- A comprehensive list of all SmartWay carriers that the shipper uses to haul their freight for the reporting calendar year (this list should include all truck, rail, multimodal, barge, air, and logistics companies hired by the shipper).

Additional information is needed depending on the shipper's selected level of participation. There are 4 ways shippers can participate in SmartWay. Way 1, the SmartWay Candidate level, is only for companies who want to learn more about SmartWay before joining as a SmartWay Shipper Partner. To become a SmartWay Shipper Partner, you select Way 2, Way 3, or Way 4. Under Way 2, 3, or 4, shippers participate as full SmartWay partners and submit activity and performance data using the SmartWay Shipper Tool. Note that Way 2 participants will not generate an emissions footprint, and will not be eligible for an annual SmartWay Award.

Way 2 data requirements:

- A non-mileage-based measure of how much business you do with each carrier. Examples include the amount of money you spend with each carrier, or the number of shipments per carrier
- Description of data sources used to compile the alternative activity metric

Way 3 data requirements:

- Activity data for all the carriers the shipper uses including
 - Total miles contracted, ton-miles contracted, and/or average payload data for each SmartWay and non-SmartWay carrier
 - Description of data sources used to compile activity data

Way 4 data requirements:

- All data required for Way 3 participation, plus at least one of the following
 - Information to differentiate the freight the company moves with any individual carrier by various methods, such as inbound versus outbound, domestic versus international, business unit, internal ID code, or other custom method
 - Information to evaluate company operational strategies to eliminate miles or weight from the freight operations to reduce the shipper's carbon footprint
 - Information to evaluate strategies to shift freight transportation from one mode to another (e.g., from truck to rail)

This data should be provided for all of the shipper's companies. This data reflects the amount of freight carried by each carrier, the distance that freight is carried, and the fuel consumed to carry the freight.

SmartWay Shipper partners are encouraged to participate at the Way 4 level and use the performance assessment and strategy evaluation tools as a core element of their businesses' environmental sustainability planning processes as well as core corporate decision-making.

What Software & Hardware Is Required For Completing The Shipper Tool?

The Shipper Tool was designed in "Microsoft Excel Forms." Completing the Shipper Tool requires the following software and hardware:

- A 2007 or later version of Microsoft Excel*
- Excel security level set at Medium or lower
- A PC running Windows XP or newer operating system (the tool does not currently work using the Mac operating system)
- A minimum of 15 megabytes of free disk space. More disk space may be required based on the number of companies you define in your tool
- A monitor resolution of at least 1,024 x 768

* The Excel web application in MS Office 365 (the cloud-based version of the Office operating system) does not currently support the macros used in the SmartWay tools. Therefore, SmartWay tools do not function properly in Office 365 at this time.

Please check with the user specifications for your computer, online support, or your company's IT department to make sure your system is set up to use the Shipper Tool.

HOW DO I SET THE SECURITY LEVEL WHEN OPENING SMARTWAY TOOLS?

Macros must be enabled on your computer to use the Shipper Tool.

The default macro security setting in Excel is "Disable all macros with notification" When you open the tool, you may get a security alert that macros are present, and you need to choose to enable the macros for this file to work. The steps below describe how to enable macros for different versions of Excel, first if the message bar or security dialog appear, and alternatively in the Trust Center if the message/dialog do not appear.

Enable macros when the Message Bar appears (Excel 2016, 2013, and 2010)

1. When you open the tool, the yellow message bar appears with a shield icon and the **Enable Content** button.

1 Security Warning Macros have been disabled. Enable Content

2. On the Message Bar, click Enable Content.

Note: if the file opens in Protected View, click **Enable Editing** on the message bar. If there is no Enable Editing option, click **Click for more details** and then click **Edit Anyway.** The Protected View message will look similar to the image below:

PROTECTED VIEW Office has detected a problem with this file. Editing it may harm your computer. Click for more details.

PROTECTED VIEW This file was opened in Protected View. Click for more details.

Once editing is enabled, follow Steps 1 and 2 above to enable content on the macro message bar.

Enable macros when the Security Options dialog appears (Excel 2007)

1. When the Security Options dialog appears, click Enable this content

Excel 2007 Security Options dialog



<u>If the Message Bar or Security Options dialog does not appear, change macro settings in the Trust</u> <u>Center</u>

Change macro settings in the Trust Center (Excel 2016, 2013, 2010, 2007)



- 1. Click the File tab (Excel 2016, 2013, 2010) or the Microsoft Office Button (Excel 2007)
- 2. Click Options (Excel 2016, 2013, 2010) or Excel Options (Excel 2007)
- 3. Click Trust Center, and then click Trust Center Settings.
- 4. In the Trust Center, click Macro Settings.
- 5. Click the option "Disable all macros with notification."
- 6. Click **OK**.
- 7. Close out of the Excel file and then re-open it.

8. Follow the previous instructions to <u>Enable macros when the Message Bar or Security Options</u> <u>dialog appears</u>

The following image is the Macro Settings area of the Trust Center.

ist Center		1 1 1 × 1
Trusted Publishers Trusted Locations Trusted Documents Add-ins ActiveX Settings Macro Settings Protected View Message Bar File Block Settings Prwacy Options	Macro Settings	
		OK Cancel

Once macros are enabled (and you are not in Protected View), you should be able to proceed with running the Tool.

If, at this point, the Tool does not open, review the "Software and Hardware Requirements". If you after reviewing this section, you cannot determine how to correct the problem, contact your SmartWay Partner Account Manager.

What Is Included In The SmartWay Shipper Company Partnership Agreement?

To join the SmartWay Transport Partnership as a shipper company, you must agree to the language on the "Partnership Agreement for Shippers." When you begin working within the tool, you will be asked to check a box stating that you agree to the terms of the partnership agreement. **This agreement must be renewed annually.**

Please review this language with the appropriate personnel within your organization before completing or submitting a Tool to EPA.

Partnership Agreement for Shippers

With this agreement, your company joins EPA's SmartWay Transport Partnership and commits to:

- 1. Measure and report to EPA on an annual basis the emissions performance of your company using EPA's SmartWay Shipper Tool. (Existing companies must report the 12 months of data for the prior year ending December 31. Newly formed companies require a minimum of 3 months of operational data.)
- 2. Agree to SmartWay listing your name on the SmartWay Transport Partnership website as a Partner company.
- 3. Agree to submit supporting documentation to EPA for any data used to complete this tool and agree to EPA audit of this data upon request by EPA.
- 4. Treat individual corporate data as sensitive business information.

In return, EPA commits to:

- 1. Promote company participation in the Partnership by posting Partner names on the EPA SmartWay website and in related educational, promotional, and media materials. EPA will obtain express written consent from the Partner before using the Partner's name, other than in the context of increasing public awareness of its participation as described here.
- 2. Provide companies with industry-wide performance benchmark data as this data becomes available to EPA.²
- 3. Assist Partners in achieving emission and fuel usage reduction goals (subject to Federal Government Appropriations).

General Terms

- 1. If the Partner or EPA defaults upon this agreement at any point, the agreement shall be considered null and void.
- 2. Either party can terminate the agreement at any time without prior notification or penalties or any further obligation.
- 3. EPA agrees not to comment publicly regarding the withdrawal of specific partners.
- 4. EPA reserves the right to suspend or revoke partner status for any Partner that fails to accomplish the specific actions to which it committed in the SmartWay Transport Partnership Agreement and subsequent Agreements.

² Individual corporate data will be treated as sensitive business information.

- 5. The Partner agrees that it will not claim or imply that its participation in the SmartWay Transport Partnership constitutes EPA approval or endorsement of anything other than the Partner's commitment to the program. The Partner will not make statements or imply that EPA endorses the purchase or sale of the Partner's products and services or the views of the Partner.
- 6. Submittal of this SmartWay Shipper Tool constitutes agreement to all terms in this Partnership Agreement. No separate agreement need be submitted.

Step 1—Data Collection Requirements

This section will identify data needed for completing the required sections of the Shipper Tool. **The Shipper Tool Technical Documentation** explains more about the methodological structure and technical aspects of the Tool and the data entry process; this guide will focus primarily on the essentials for completing the Tool.

INTRODUCTORY SCREENS

Upon opening the 2018 Tool, you will see a **Welcome** screen, followed by four screens which orient you to the Tool. The Assistance for New Users screen appears first and allows users to view an orientation video. Additional screens may be accessed from this screen, including data collection needs, Tool help and navigation, and the SmartWay Partner Tool Schedule for 2018. These are general information screens and may be skipped if you are already familiar with the Tool. However, upon proceeding you <u>MUST</u> select the box at the bottom of the **Partnership Agreement** screen, indicating that you agree to the terms of the Partnership Agreement for Shippers.

AUTO-POPULATION

As you progress through the Tool, you will see an **Auto-Population** screen. This screen allows partners and applicants to input their SmartWay ID and automatically load the information for the initial steps of the Tool (Partner Name, Contact Information, and for established Partners, Fleet Information), based on the prior year's submittal, or for applicants, information entered through the online SmartWay Shipper Application.³ The Auto-Population option can save time and ensure naming consistency for your contacts and company(ies) from year to year. A popup screen will appear displaying all the contact and company data uploaded for your review before proceeding. Corrections and revisions may be made on the **Home** screen if needed. If you do not have a SmartWay ID, or prefer to enter this data manually, you may skip this step.

DATA REQUIREMENTS FOR ESTABLISHING YOUR DATA COLLECTION YEAR

Before beginning your data collection, identify the last calendar year for which you have full annual (12 months) data. This means that you have data from January of the calendar year through December of the same year. If you have not been in operation for a full year, you must collect <u>**a**</u> <u>**minimum of three months' data**</u> for input into the SmartWay Tool. In your next update year, you will be expected to submit a full year's data.

³ You may access the SmartWay Shipper Application at

https://app4.erg.com/smartwayonramp/onrampShipper/step1.cfm?CFID=2146463&CFTOKEN=e2cf9fb1a41e0ca8-23E62B4F-A0E9-6413-76C4E22EFB26B419

DATA REQUIREMENTS FOR SECTION 1: SPECIFY OFFICIAL PARTNER NAME

Your Partner Name is the official name that your customers would recognize for your company in other words, the name someone hiring you would look for.

You must specify your company's official Partner Name under Section 1 of the **Home** screen, exactly as you want it to appear on the SmartWay website.

For example, you may enter:

- ABC Company
- ABC Company, Inc.

Your company will be listed *exactly* as you've entered in Section 1. Therefore, it is important to pay special attention to proper capitalization, abbreviations, annotations, and punctuation.

If you selected the Auto-populate option, please review the Partner Name as it appears on the Home screen, revising it as necessary.

DATA REQUIREMENTS FOR SECTION 2: ENTER CONTACT INFORMATION

The SmartWay Tool asks for:

- <u>General company information</u> such as location, web address, phone number, etc.
- <u>A Working Contact</u>⁴ for any questions about your company's participation and Tool submissions
- <u>An Executive Contact⁵</u> for participation in awards and recognition events
- <u>A Sustainability Contact (optional)</u>⁶ for information on company sustainability programs and outreach
- <u>Additional contacts (optional)</u>: Additional contacts may include anyone who is not the Working, Executive, or Sustainability contact but may be involved with SmartWay (e.g., press/media contact, fleet manager, etc.).

⁴ The Working Contact is the individual designated by the Executive Contact to directly interface with SmartWay regarding specific tasks involved in the timely submission of the Tool. The Working Contact is responsible for coordinating the assembly of information to complete/update company data; completing and updating the Tool itself; maintaining direct communication with SmartWay; and keeping interested parties within the company apprised of relevant developments with SmartWay.) NOTE: To ensure that emails from SmartWay/EPA are not blocked, new Working Contacts may need to add SmartWay/EPA to their preferred list of trusted sources.)

⁵ The Executive Contact is the company executive who is responsible for agreeing to the requirements in the SmartWay Partnership Agreement, overseeing the Working Contact (as appropriate), and ensuring the timely submission of the Tool to SmartWay. The Executive Contact also represents the company at awards/recognition events. This person should be a Vice President or higher-level representative for the company.

⁶ The Sustainability Contact may be the same as the Working or Executive Contact, but not the same as any Other Contacts.

Note that you MUST have at least two contacts listed in the contact information section of the Tool, and the Working and Executive Contacts must be different, in order to proceed. SmartWay recommends developing an internal succession plan to make sure that your Logistics Tool submission schedule is maintained, in the event that a Working Contact is reassigned, or leaves the company for any reason.

If you selected the auto-populate option you still MUST review the Contact Information that pops up before leaving the **Auto-population** screen, and revise any entries on the **Home** screen as needed.

DATA REQUIREMENTS FOR SECTION 3: COMPANY DESCRIPTION

This section of the Tool allows you to create multiple company data records. If you operate more than one separate and distinct company you may wish to track each company separately. Each individual data file has the ability to track companies, inbound/outbound freight, and international/domestic freight as well as other user-defined distinctions.

Most Partners should create one company. However, if you are a global conglomerate that, for example, has a large home goods retail company, a wholesale parts supply company, and a product manufacturer, all with separate corporate identities and transportation systems, you may want to create three companies. However, note that these companies will not be listed separately on the Partner Listing on the SmartWay website. If you would like multiple companies displayed on the Partner Listing, submit separate Tools for each company.

The **Company Description(s)** screen requires the following information:

- **Company Name(s)**: Name your companies, beginning with your partner name followed by the specific company name. Example: Shipper Company 1 Retail.
- NAICS Code: NAICS, or North American Industry Classification System codes, are the Federal standard for classifying businesses by activity type. NAICS codes can be from two or three up to six digits in length, and are organized hierarchically, with successive digits providing greater specificity in its description. Use the NAICS code(s) that most appropriately describes your company. You can use the search icon to the right of the data entry field to identify and select NAICS code(s). If you need to enter multiple NAICS codes, you may check multiple boxes on the popup screen while holding down the "Ctrl" key on your keyboard, or simply enter them directly and separate them with commas.

Detailed information on NAICS codes can be found at <u>http://www.census.gov/eos/www/naics/</u>. Alternatively, you may locate your NAICS code:

- 1. On your company's 1120 corporate tax return, filed with IRS, Schedule K, lines 2a, b and c.
- 2. Or, on the 1120S corporate tax return, filed with IRS, Schedule B, lines 2a and b.

If you selected the auto-populate option you still MUST review the Company Description information that pops up before leaving the **Auto-population** screen, and revise the entries on the **Home** screen as needed.

DATA REQUIREMENTS FOR SECTION 5: PARTICIPATION LEVEL AND DATA INPUT METHOD

No data are needed to complete section 5, however you must choose the level at which you wish to participate and select how you would like to input data into the Tool. These choices will affect data needed to complete the next section. On the **Participation Level** screen, you have the option to choose to participate at the Way 2, Way 3, or Way 4 level. The table below summarizes the three options and describes who the option is best for, the benefits, inputs needed, and the input methods available.

Option	Way 2: Basic Freight Assessment	Way 3: Standard Freight Assessment	Way 4: Advanced Freight Assessment
Best for:	Shippers with limited data that wat	Shippers that want a freight	Shippers that want a more-detailed
	to start freight efficiency planning.	emissions footprint to guide their	freight emissions footprint and
		freight decision making.	added analysis.
Inputs	Carrier names and relative data	Carrier names; mileage, ton-miles	Carrier names; mileage, ton-miles
needed:	(e.g., amount spent, number of	and/or payload data per carrier	and/or payload data per carrier;
	shipments, volume shipped, or		and additional operational
	another custom metric)		strategies and mode split data
Input	Manual only	Manual or data import	Manual or data import
methods:			
Benefits:	 Define a relative freight 	All the benefits of Way 2 plus the	All the benefits of Way 3 plus the
	performance metric (%	ability to:	ability to:
	SmartWay)	 Build a freight performance 	 Subdivide freight activity based
	 Be recognized as a Smartway 	assessment based on per carrier	on inbound vs outbound,
	Partner	mileage and payload	domestic vs international,
		• Compete for recognition through	discrete business units, and/or
		the SmartWay Excellence Awards	other criteria
			Compare emissions savings from
			various mode and operational
			strategy changes
			Receive additional credit for
			SmartWay Excellence Award

DATA REQUIREMENTS FOR SECTION 6: DATA ENTRY

In Section 6 of the Shipper Tool, you will identify the carriers included in each of your shipper companies, and then enter either **detailed activity data** or **relative carrier data** depending on the participation level selected. The screens you must complete will depend on the participation level and data input method you specified in the previous section.

Data Requirements for Inputting Carriers

In this section, you must specify the carriers that your shipper company uses. There are different methods to select carriers depending on your level of participation and input method selected in the previous section, but regardless of the method you choose, you will need to first identify the mode of transport for the carrier. Six carrier mode selections are available, including:

- Rail
- Truck
- Multimodal
- Logistics
- Barge
- Air

Next, you may also specify a SmartWay Category for the Truck and Multimodal modes. Truck SmartWay Categories include:

- Auto Carrier
- Dray
- Expedited
- Flatbed
- Heavy/Bulk
- LTL Dry Van
- Mixed
- Moving
- Package
- Refrigerated
- Specialized
- Tanker
- TL Dry Van

Multimodal SmartWay Categories include:

- Surface
- Surface-Air
- Surface Marine
- Surface-Air-Marine

SmartWay Category selections are not currently available for other modes but may be added in the future.

After identifying the mode (and SmartWay Category, if available), you should identify each carrier's specific fleet name, as listed in the SmartWay Carrier Data file, along with any associated SCACs, DOT numbers, MCNs, and NSCs.

After identifying your SmartWay carriers, you must also enter the number of non-SmartWay carriers used by the shipper company. *Only include carriers used during the reporting year*. If this company has non-SmartWay carriers, you will also select the carrier mode(s) the non-SmartWay carrier(s) belong to. For truck carriers, specify the appropriate carrier type (e.g., non-SmartWay Dray). If you are not sure of the appropriate truck carrier type, select the "General" option.

Details on data entry and which screens you will have to complete depending on your participation level and input method selections are described in the Step 2 – Data Entry section below.

Data Requirements for Carrier Subdivision Screen

NOTE: This screen is only applicable to the Way 4 participation level.

If you selected the Way 4 participation level, you may specify supplemental information to help you further characterize your carrier use on this screen. For example, you can designate certain carriers used for domestic or international routes. The optional information may be applied to any carrier and include the following:

- Company Identifier
- ID Code
- Inbound/Outbound/Internal
- Domestic/International
- Internal Shipper Segment 1
- Internal Shipper Segment 2

You must complete this screen, the **Mile & Weight Improvements** screen, or the **Modal Shift Impacts** screen if you selected the Way 4 level.

Data Requirements for Activity Data

NOTE: This screen is only applicable to the Way 3 and Way 4 level.

After identifying your carriers, you will be taken to the **Activity Data** screen. First provide a detailed text data source description for the sources used to estimate your mileage, ton-mile and payload data for your carriers by selecting the **Describe Data Source** button. Be sure to indicate how you calculated the values, and where this data was obtained. For example, you may use carrier reports or accounting/purchasing records to determine miles. Payload and ton-mile estimates may be based on bills of lading or other internal records.

Next, identify any carrier fleets operated directly by your shipper company by checking the "Shipper Carrier" box. This allows the Tool to exclude these carriers from the Scope 3 emissions calculations provided in the **Public Disclosure Report**. See the <u>Shipper Tool Technical Documentation</u> for further details on the **Public Disclosure Reports**.

Next you must specify a **Data Availability** option for each carrier. There are four **Data Availability** options:

- a. Enter ton-miles and total miles (preferred option)
- b. Enter ton-miles and average payload
- c. Enter total miles and average payload
- d. Enter total miles only

You should use the option for which you have the most reliable data:

- If you have reliable data for both ton-miles and miles, you should select Option a.
- If you don't have reliable miles data, but do have reliable ton-mile data, select Option b.
- If you don't have reliable ton-miles data, but do have reliable miles data, select from options c or d.

NOTE: LTL and Package carriers may not select Option d, due to the importance of estimating precise payloads for these carrier types.

Choose the method that uses the most accurate data at your disposal for each carrier. In this way the Tool will utilize the most accurate data available for the ton-mile and mile comparison metrics as well as for the emissions footprint calculations.

If the carrier mode is rail, you will need to record total railcar-miles, or if barge, then barge-miles, otherwise you must specify total truckload-miles. Enter the data to the nearest whole number.

Data Availability Option a – Enter total ton-miles and total miles. Total miles corresponds to truck miles, railcar miles, or barge miles, as appropriate. For rail carriers, DO NOT enter train miles, and for barge carriers, DO NOT enter miles for the entire string of barges – enter the sum of miles for each individual railcar and/or barge load.

Data Availability Option b - Enter total ton-miles along with your estimated average payload (per truck or railcar, as appropriate) in short tons (2,000 lbs.)

Data Availability Option c - Enter total miles along with your estimated average payload (per truck, barge or railcar, as appropriate) in short tons (2,000 lbs.)

Data Availability Option d - Enter total miles.

IMPORTANT: Correctly calculating Ton-Miles is critically important for the accurate determination of your carbon footprint.

You can calculate your company's ton-miles as follows:

Enter the ton-miles hauled per year attributable to each carrier. A ton-mile is one ton moving one mile. DO NOT ESTIMATE TON-MILES BY SIMPLY MULTIPLYING TOTAL MILES BY TOTAL TONS - this calculation effectively assumes your entire tonnage is transported on EACH AND EVERY truck, and will clearly overstate your ton-miles.

There are two ways to calculate ton-miles:

- 1. Companies can determine their average payload per carrier, multiply the average payload by the total miles per carrier, and sum the results for all carriers for the reporting year; or
- 2. Set Ton-miles per carrier = <u>(total miles per carrier x total tons per carrier)</u> total # of trips per carrier

To check your estimate, divide ton-miles by miles. The result is your fleet-average payload. If this number is not reasonable, please check your calculations.

Data Requirements for "% SmartWay"

Carriers identified in the **Input Carriers** screens are automatically carried over to this screen. If you selected the Way 3 or Way 4 participation level, the fractional mileage and ton-mile amounts attributable to each carrier are also shown here and may be used as weighting factors across your carriers to calculate your **% SmartWay Value**. There are no data requirements for the ton-miles and total miles weighting factors on this screen

If you selected the Way 2 participation level you must specify an alternative weighting factor to apply across the different carriers, such as the percentage of total payments, the percentage of total weight or total packages, or an alternative "custom" for calculating your % SmartWay Value. In this case you must enter the type of data you use for your percentage allocation estimates using the drop-down menu at the top of the screen, and then enter the percent allocated to each carrier. Percentages must sum to 100. You must also document the custom factor methodology in the text box presented at the lower left of the screen.

Note: If you are participating at the Way 2 level, you will not see the Ton-Mile or Total Mile columns presented on the **% SmartWay** screen.

Mile & Weight Improvements Data Requirements

NOTE: This screen is only applicable to the Way 4 participation level.

This screen allows you to estimate the emissions savings impacts for a range of activities and best

practices which impact the emission footprint of the transportation supply chain (e.g., reducing miles traveled in the transportation network through route or cube optimization, or reducing weight through package reduction, among others). You should have data about your company's activities or possible activities to complete this screen. You must complete this screen, the **Carrier Subdivision** screen, or the **Modal Shift Impacts** screen if you selected the Way 4 level.

Modal Shift Impacts Data Requirements

NOTE: This screen is only applicable to the Way 4 participation level.

The **Modal Shift Impacts** screen allows partners to evaluate the emissions impact of moving to different modes (e.g. truck-to-rail or rail-to-barge). You need data about potential modal shifts in order to complete this screen. You must complete this screen, the **Carrier Subdivision** screen, or the **Mile & Weight Improvements** screen if you selected the Way 4 level.

Step 2—Data Entry

DOWNLOADING THE SMARTWAY SHIPPER TOOL

To download the SmartWay Logistics Tool, visit: <u>https://www.epa.gov/smartway/smartway-shipper-partner-tools-and-resources</u>. Save the Tool in a folder on your hard drive; this folder will house copies of your data and future updates.

ENTERING PARTNER NAME

Under Step 1 on the Home screen:

- 1. Type your **Partner Name** EXACTLY as you would like it to appear on the SmartWay website and in other EPA communications in the field as indicated.
- 2. Proceed to Section 2 to enter Contact Information.

ENTERING CONTACT INFORMATION

Note: Use the Tabs at the top of the window to navigate between the 5 information screens

SmartWay: Contact Information X									
Partner Information Working Contact Executive Contact Sustainability Contact Other Contacts									
Each field marked with an asterisk must be filled out. You will not be able to submit the Tool									
to SmartWay without this information.									

Under the Partner Information tab:

1. Enter the Company address, phone numbers, and website (optional).

2. Enter the Working Contact name and title.

The **Working Contact** is the individual designated by the Executive Contact to directly interface with SmartWay regarding specific tasks involved in the timely submission of the Tool. The Working Contact is responsible for coordinating the assembly of information to complete/update fleet data; completing and updating the Tool itself; maintaining direct communication with SmartWay; and keeping interested parties within the company apprised of relevant developments with SmartWay.

NOTE: To ensure that e-mails from SmartWay/EPA are not blocked, new contacts may need to add SmartWay/EPA to their preferred list of trusted sources.

3. Enter the Executive Contact name and title.

The **Executive Contact** is the company executive who is responsible for agreeing to the requirements in the SmartWay Partnership Annual Agreement, overseeing the Working

Contact (as appropriate), and ensuring the timely submission of the Tool to SmartWay. The Executive

Contact also represents the company at awards/recognition events. This person should be a Vice President or higherlevel representative for the company.

4. Enter the Sustainability Contact name and title (optional).

The **Sustainability Contact** is the individual assigned responsibility for monitoring the company's environmental performance. The Sustainability Contact may be the same as the Working or Executive Contact (and specified by checking the "Same as" boxes in the Sustainability Contact section), but cannot be the same as any Other Contact.

5. Enter Other Contact names and titles.

Under the Working Contact tab:

Enter the Working Contact information. If the Working Contact shares the same address as the company, you may select the **Partner Address** button to auto-populate the address section of this record. Enter the email address twice to confirm its accuracy.

Under the Executive Contact tab:

Enter the Executive Contact information, including the contact email address. The same buttons and fields are available as described for the Working Contact tab.

Under the Sustainability Contact tab:

If applicable, enter the Sustainability Contact information including the contact email address. The same buttons and fields are available as described for the Working Contact tab.

Under the Other Contacts tab:

- 1. Enter Other Contacts (if applicable) by selecting the Add New Contact button.
- 2. Enter the first Other Contact then select the **OK** button when done.

NOTE: You must supply at least two unique contacts on the contact screen to ensure EPA has access to at least two people for Tool submission follow-up.

NOTE: In some cases, companies with multiple fleets will gather information from different sources within the company. You may find it useful to have this additional contact information stored within the Tool. You can add more contacts to the **Other Contacts** box by repeating this process. If you wish to edit an existing contact's information, highlight the name you wish to edit and then select the **Edit Selected Contact** button. You can remove an existing contact by highlighting the contact and then selecting the **Delete Selected Contact** button.

To make sure you have filled out all required contact information, select the **Validate Screen** button at the bottom of the screen on the **Partner Information** tab. If any information is missing or invalid, a dialogue box will appear informing you what additional information is required.

Next select the **HOME** button to return to the **Home** screen and proceed to Step 3.

COMPLETING THE COMPANY DESCRIPTION SCREEN

- 1. On the Home screen, select the Company Description(s) button to display the Company Description screens.
- 2. Enter the "Company Name" for your first (or only) company.
- 3. Enter the NAICS code for each of your companies. You may enter multiple NAICS codes if appropriate. You may enter NAICS codes in two ways:
 - a. Manually type in two- to six-digit NAICS codes, separated by commas, in the space provided.
 - b. For help finding your NAICS code, select the binoculars button to the right of the data entry field. A separate form that includes all NAICS codes and their descriptions will appear. You may select one or multiple NAICS codes from this screen. To select multiple codes, press the "Ctrl" button on your keyboard (and keep it pressed) and then select the items from the list box with your mouse. Select **OK** when finished to insert the selected NAICS onto the main screen.
- 4. Enter additional companies as needed:
 - a. To enter another company, select the **Add Company** button.
 - b. To delete a company, select the box next to the row you wish to delete, and then select the **Delete Checked Rows** button.
 - c. Once you have entered the Company Name and specified the associated NAICS code(s), select the **CREATE COMPANIES** button and return to the **Home** screen.

DOWNLOADING THE LATEST SMARTWAY CARRIER DATA FILE

- 1. On the **Home** screen, select the **Download Latest SmartWay Carrier Data File** button under Step 4 and allow the Tool to download the latest carrier data (SmartWayCarrierData2017ST.xlsx).
- 2. Proceed to Step 6 to enter data for your company(ies).

SELECTING A PARTICIPATION LEVEL

- 1. On the Home screen, select the "Participation Level and Data Input Method" button to proceed to the Participation Level screen at Step 5.
- There are three program participation levels from which to choose when filling out the Shipper Tool. All choices allow you to be a SmartWay partner. Some choices will require more data entry than others but will give you better and more useful results. The **Participation Level** screen walks you through your choices, described below.

Note: carefully consider the information you have available for your carriers in order to select the best option for your company. Your participation level will determine the extent to which your tool outputs will yield performance assessments that allow you to track your progress and compare it to others, as well as your eligibility for the various types of SmartWay performance awards.

Way 2 – Basic Freight Assessment: This option allows you to input your carriers and a non-mileagebased measure of how much business you do with each carrier. Examples may include the amount of money you spend with each carrier, or the number of shipments per carrier. Partners participating at the Way 2 level will learn what percentage of their freight is with SmartWayregistered carriers, although they are not eligible for an annual SmartWay performance award.

Way 3 – Standard Freight Assessment: This option allows you to input your carriers and how much freight they move for you, expressed in miles and/or ton-miles. This option provides partners with information on total mass emissions generated and the associated efficiency for CO₂, NO_x, and PM emissions. Partners can view emissions and performance by carrier, mode of transport, or at the company level. Partners can also import data rather than input it manually, as described on the next screen. Partners participating at the Way 3 level are eligible to compete for recognition through the SmartWay Excellence awards.

Way 4 – Advanced Freight Assessment: This option allows you to differentiate your freight movement with individual carriers by various methods such as inbound versus outbound, domestic versus international, business unit, internal ID code or other custom method. This selection also provides the option of determining emission savings from specific operational practices and mode shifts such as moving freight from truck to rail. Partners participating at the Way 4 level must complete at least one of the following screens: Carrier Subdivision, Mile & Weight Improvements, or Modal Shift Impacts. Partners will earn receive additional credit for the SmartWay Excellence Award for completing these screens.

- 3. Select the SmartWay Awards Information button at the bottom of the screen for further details.
- 4. Select a participation level before proceeding. If you select Way 3 or Way 4, click the "**NEXT**" button to proceed to the **INPUT METHOD** screen. If you select Way 2, click the **HOME** button to proceed to the next step. If you want to change your mind, you can return to the **Participation Level** screen at any time and update your selection.

SELECTING THE DATA INPUT METHOD

1. If you selected the Way 3 or Way 4 participation level you will need to complete the **Input Method** screen. Select the data input method based on the number of carriers you use, and your ability to process and import carrier-specific data in the proper format (CSV). Input options include:

Manual Input Only - This option is best for Shippers with fewer than 100 carriers, or for those who are not comfortable with the **Data Import** option (see below). By choosing **Manual Input Only** you will add your carriers to a data entry list by selecting them from a listbox. There are various ways to sort and filter carriers for selection (e.g. by carrier mode, SCAC, etc.) After selection you will enter data for each carrier, namely miles, ton-miles, and/or average payload. If you already have your carrier activity data compiled, entry time should be about one minute or less per carrier for most people.

Data Import - This option is best for shippers that have over 100 carriers, and/or you are participating at the Way 4 level. This option involves creating a data file for import into the Shipper Tool. It can save time if you are able to export data from your own information technology system. There are several ways to create these files and they are explained in detail within the Tool. This option provides users with the ability to also use the **Manual Input Only** screens to edit data. If you are not comfortable with creating external data files, then the **Manual Input Only** option may be better suited to you. The **Data Import** method is described in detail in the **Guide to Importing Carrier Data Using the Outside Data Import Function** at https://www.epa.gov/smartway/smartway-shipper-partner-tools-and-resources.

2. Select your preferred data input method and click the **HOME** button to proceed to the next step. You may return to this screen later to select a different option if needed.

SELECTING A COMPANY FOR DATA ENTRY

On the **Home** screen, you will now see all the shipper companies you created listed in the window below Step 6: **Data Entry**. There will be a status message after each company, indicating whether or not the data entry for that company is complete. The following information may appear beside a company name, depending upon where you are in the data entry process:

- Not checked Data has not been entered yet.
- Incomplete Some data is still missing and/or inconsistent.
- **Complete** All data requirements have been met and validation has occurred.

In addition to the status indicators above, you may also see one of two qualifiers: "Errors" or "Warnings."

• Errors will prevent you from checking your emissions and performance under the **Review Your Results** section (Step 7), and must be addressed before you can submit your Tool to EPA. • Warnings will still allow you to proceed and submit your data to EPA. However, it is strongly recommended that you carefully review each warning message before sending your data to EPA so that you can anticipate questions that may come from a Partner Account Manager as a result of your data being outside the expected ranges. The method addressing errors and warnings is described for subsequent input screens in the following sections.

To begin your data entry:

- 1. Using your mouse, on the **Home** screen select and highlight the name of the shipper company for which you wish to enter data.
- 2. Double click the name; you will then be taken to the data entry screens for that company.

INPUTTING CARRIERS FOR A COMPANY

- If you selected the Manual Input Only option on the Input Method screen, you will arrive on the Manual Input SmartWay Carriers screen after you double-click a company name at Step 6 on the Home screen. You will use this screen to identify the SmartWay partners utilized by your shipper company, and then you will proceed to the Manual Input Non-SmartWay Carriers screen to enter your non-SmartWay carriers. See "Completing the Manual Input SmartWay Carriers Tab" and "Completing the Manual Input Non-SmartWay Carriers Tab" below for details.
- 2. If you selected **Data Import** option on the **Input Method** screen, you will arrive on the **Instructions** screen, which describes the two ways to populate the Tool with company information via Data Import/Export and Carrier Matching.
 - a. The Data Import/Export approach allows partners to export and import carrier lists in a standardized format, as described in detail on the **Outside Data Import** and **Export Carriers** screens. See the <u>Guide to Importing Carrier Data Using the Outside Data Import Function</u> at <u>https://www.epa.gov/smartway/smartway-shipper-partner-tools-and-resources</u> for detailed instructions on the export/import process.
 - b. The Carrier Matching approach utilizes a function (described on the Match My Carriers screen) to find and match SmartWay carriers based on a wide range of criteria, including their own internal carrier identification, such as carrier ID codes, with records in their Tool submission from a prior year. The carrier matching function provides an efficient, reliable means of linking a company's carrier list to the correct records in the carrier data file, ensuring shipper companies obtain full credit for their use of SmartWay carriers. Partners may also enter new codes for matching carriers in future years. Your company-specific match data is not shared with other companies. The matching process is explained in detail on the Match My Carriers screen.
 - c. After using the **Data Import/Export** and/or **Carrier Matching** screens, you will also be directed through the two manual input screens. You may review selected carriers that were

imported on the **Manual Input SmartWay Carriers** screen if you like (and add/delete selected carriers), and then you must complete the **Manual Input Non-SmartWay Carriers** screen before proceeding.

COMPLETING THE MANUAL INPUT SMARTWAY CARRIERS SCREEN

- To select carriers manually, you can enter all or part of the carrier's name directly into the Carrier Name input box and the select the Apply Filter button. A new filtered list will appear in the Available SmartWay Carriers box. Double click on the carrier name to add it to the Selected SmartWay Carriers box.
- 2. You may also search for carriers by filtering using carrier mode, SmartWay Category, SCAC, MCN, DOT, NSC, and/or various address fields to find your carriers in the SmartWay Carrier data file.
- To search by Carrier Mode, select the mode of transport from which you wish to choose a carrier. Seven carrier mode selections are available, including "All," "Rail," "Truck," "Multimodal," "Barge," "Logistics," and "Air."
 - Note that by selecting "All," you may search across all carriers, regardless of mode.
 - Next, if you select the Truck mode, you may also specify a SmartWay Category. Truck ranking categories include TL Dry Van, LTL Dry Van, Refrigerated, Flatbed, Tanker, Dray, Heavy/Bulk, Package, Auto Carrier, Moving, Specialized, Mixed, and Expedited. Alternatively, if you select the Multimodal mode, available SmartWay Categories include Surface (i.e. truck/rail), Surface-Air, Surface-Marine, and Surface-Air-Marine.
- 4. Once you have applied the desired filters, a list of available SmartWay carriers meeting your filter criterion appears in the "Available SmartWay Carriers" box. Using your mouse, double click on the carrier name to add it to the "Selected SmartWay Carriers" box. You may also use the **Add Selected Carriers to List Below** button to add selected carriers to the "Selected SmartWay Carriers" box.
- 5. Once you have successfully identified your carriers, proceed to the Manual Input Non-SmartWay Carriers tab.

COMPLETING THE MANUAL INPUT NON-SMARTWAY CARRIERS SCREEN

- 1. Enter the total number of Non-SmartWay Carriers for the company into the data field.
- 2. Check the box to confirm that you have added all of the Non-SmartWay Carriers for your company.
- Using your mouse, double-click on each non-SmartWay carrier <u>type</u> used by this company; double clicking will add it to the "Selected Non-SmartWay Carriers" list. You may also use the Add Selected Carrier Types to List Below button to add selected carrier types to the "Selected Non-SmartWay Carriers box."

- For truck and multimodal carriers, select the appropriate SmartWay Category (e.g., TL/Dry Van, Refrigerated, Dray, etc.). If you are not sure about a specific truck carrier's category, select the "General" option.
- Also distinguish your air carriers by "long haul" (cross-country/overseas flights, > ~2,300 miles) and "short haul" (generally regional/domestic flights, < ~2,300 miles).
- 4. Once the required data has been entered on the **Manual Input Non-SmartWay Carriers** screen, you can proceed to the **Activity Data** screen.

COMPLETING THE CARRIER SUBDIVISION SCREEN

- If you have selected the Way 4 participation level, you must complete this screen, or the Mile & Weight Improvements screen, or the Modal Shift Impacts screen, or any combination of these screens. You will not see this screen if you have selected Way 2 or Way 3.
- Look near the top of the screen for the complete list of the carrier names you have specified up to this point, along with carrier information such as mode, SmartWay Category, and SCAC/MCN/DOT/NSC.
- 3. To provide additional information for a given carrier, highlight the carrier name in the upper list box and you will see the carrier name appear in the lower list box. There will be only one row per carrier if you have not added carrier subdivision yet.
- 4. Choose a row for the carrier in the bottom list box to enable the fields that allow you to add information to differentiate your carriers, such as inbound/outbound, domestic/international, etc.
- 5. Type in or select from the drop-down menus the additional information for the selected carrier row. When you are through editing, select the **Apply Descriptive Data to Selected Carrier** button to save your changes. You will see your changes added to the bottom list box for the selected carrier row.
- If you wish to differentiate the activity associated with a single carrier (e.g., splitting inbound and outbound freight movements), highlight the carrier name in the upper list box select the Add Row for Selected Carrier button immediately below the box.
- You will now see an additional row appear in the lower list box with the same carrier name. Enter the different information for each row as described above, and repeat the process as many times as necessary.
- Rows in the lower text box may be deleted by highlighting them and selecting the Delete Selected Carrier's Optional Information button at the bottom right. Once finalized, your complete list of differentiated carrier rows will be brought forward to the Activity Data screen.

9. Proceed to the **Activity Data** screen to input the mile, ton-mile and/or payload data associated with each of your carriers using the Tool itself. If you subdivided a given carrier, you must provide separate activity data inputs for each carrier row.

NOTE: Before proceeding to the **Activity Data** screen, check your carrier listing to be sure the list includes all carriers that your company uses, and that the names, SCACs, MCNs, NSC, and DOT numbers match exactly. You may review your carrier list using the **Input Summary Report** available under the **View Summary Data Reports** button on the **Home** screen.

COMPLETING THE ACTIVITY DATA SCREEN

- 1. Select the **Describe Data Source** button.
- 2. Enter a detailed description of the sources used for your Activity data information, including a description of how you calculated miles, ton-miles, payload, density and load percent (if applicable) in the space provided.
- 3. Select the **CLOSE** button.
- 4. Next, identify any carrier fleets operated directly by the shipper company by checking the Shipper Carrier box. This allows the Tool to exclude these carriers from the Scope 3 emissions calculations provided in the Public Disclosure Report (included in the View Summary Data Reports menu). See the Shipper Tool Technical Documentation at https://www.epa.gov/smartway/smartway-shipper-partner-tools-and-resources for further details on the Public Disclosure Reports.
- 5. For each carrier listed, specify your data availability:
 - a = I know both Ton-miles and Total Miles
 - b = I know Ton-miles and Average Payload
 - c = I know Total Miles and Average Payload

d = I know Total Miles only (excluding LTL, and Package Truck Carriers, due to the difficulty in adjusting mileage for partial loads)

- 6. For carriers where you have selected **Data Availability Option a**, enter total ton-miles along with total miles.
- For carriers where you have selected Data Availability Option b, enter total ton-miles along with your estimated average payload (per truck, barge, or railcar, as appropriate) in short tons (2,000 lbs).
- 8. For carriers where you have selected **Data Availability Option c**, enter total miles along with your estimated average payload (per truck, barge, or railcar, as appropriate) in short tons (2,000 lbs).
- 9. For carriers where you have selected **Data Availability Option d**, enter total miles.

- 10. Select the **VALIDATE SCREEN** button and correct any errors.
 - a. If you have errors, they will appear either as red boxes for significant errors, or as yellow warning boxes for less-extreme errors. Red errors will prevent you from submitting your Tool.
 - b. If your values are out of range, but you are confident that they are correct, double click the box with the error. A comment box will then appear. Enter an explanation for the value and click **OK**. The box will become yellow, and you will be able to proceed to submit your Tool.
- 11. Select the **NEXT** button to proceed to the **% SmartWay** screen.

COMPLETING THE % SMARTWAY SCREEN

- Select the weighting factor you wish the Tool to use to determine your % SmartWay Value, corresponding to the percent of your activity attributable to SmartWay carriers. Comparing your % SmartWay Value over time provides a useful way of gauging your company's progress in reducing its overall emissions or footprint. Select the radio button for Ton-Miles or Total Miles to choose the weighting factor for all your shipper companies.
- 2. Your actions for the next step depend upon your chosen participation level:
- If you selected the Way 2 participation level, you must specify an alternative weighting factor to apply across the different carriers, such as the percentage of total payments, the percentage of total weight or total packages, or an alternative "custom" factor for calculating your %
 SmartWay Value, by selecting one of the options in the drop-down menu. Enter the type of data used for your percentage allocation estimates using the drop-down menu at the top of the screen, and then enter the percent allocated to each carrier. Percentages must sum to 100. The resulting weighted average % SmartWay Value is displayed at the bottom right of the screen. You must also document the custom factor methodology in the text box presented at the lower left of the screen.
 - **Note**: If you are participating at the Way 2 level, you will not see the Ton-Mile or Total Mile columns presented on the **% SmartWay** screen.
- <u>If you have selected the Way 3 or Way 4 level</u>, select the radio button for Ton-Miles or Total Miles to choose the weighting factor for all your companies. The default value will be set to ton-miles.
- 3. Once you have entered your % SmartWay selections you may return to the **Home** screen if you are participating at the Way 2 or Way 3 levels. If you have defined multiple shipper companies, repeat the data entry process described above for each company.

COMPLETING THE MILE & WEIGHT IMPROVEMENTS SCREEN

- If you have selected the Way 4 level, you must complete this screen, or the Mile & Weight Improvements screen, or the Modal Shift Impacts screen, or any combination of these screens. You will not see this screen if you have selected Way 2 or Way 3.
- 2. On the **Mile & Weight Improvements** screen, select an activity category from the drop-down menu at the upper left, and then chose a specific activity from the options provided. You may select from the following options:
- Miles Removed from the System
 - Distribution center relocation
 - o Retail sales relocation
 - o Routing optimization
 - Cube optimization
 - Larger vehicles and/or trailers
 - Other (specify)
- Weight Removed from System
 - Product weight reduction
 - Package weight reduction
 - Vehicle weight reduction
 - o Other (specify)
- 3. For each strategy selected, provide an estimate of the percentage impact (in terms of miles or ton-miles, as appropriate), for each mode of interest.
- 4. Provide a text description for strategy selected, including the methods and assumptions used to estimate the changes. Based on actual data from your current carriers, the Tool will calculate the quantity of emissions changed for each pollutant.⁷
- 5. Repeat the process for each strategy that your company has implemented.
- 6. Use the **Basic Quantification and Documentation of System Activities** button on the upper right of the screen to obtain additional information regarding how operational strategies should be quantified and documented. If you have questions regarding calculations and/or documentation, contact your SmartWay Partner Account Manager.

⁷ The Tool assumes that total mass emissions are changed in direct proportion with the specified mileage or weight reductions. This assumption should be accurate for weight reduction strategies when applied to truck-load shipments that weigh out. Additional uncertainty arises though in the case of LTL and package delivery shipments, where such reductions may not result in one-to-one impact in miles hauled. Uncertainties are even greater for non-truck modes, where the shipper commonly does not control the entire content of the container.

7. Select **NEXT** to proceed to the **Modal Shift** screen.

COMPLETING THE MODAL SHIFT IMPACTS SCREEN

NOTE: The **Modal Shift Impacts** screen is intended for scoping purposes and scenario evaluations only. Shippers should develop carrier emissions inventories (and associated average emissions factors for their company) by inputting activity data in the **Activity Data** screen. The resulting estimates of emissions impacts displayed on this screen are for partner information only and are not used in determining performance estimates.

- If you have selected the Way 4 level, you must complete this screen, or the Carrier Subdivision screen, or the Mile & Weight Improvements screen, or any combination of these screens. You will not see this screen if you have selected Way 2 or Way 3.
- 2. On the **Modal Shift Impacts** screen specify the mode from which you have shifted freight or are considering shifting freight ("From Mode"), as well as the target mode ("To Mode"). You have several options for selecting an emissions factor for both the "From Mode" and "To Mode":

Shipper's Carrier Average – This option will utilize the weighted average gram per mile or grams per ton-mile metric from your carriers, for a specified mode (e.g., rail or truck), based on data you provided in the **Activity Data** screen. If this option is selected for the "From" mode, filters can also be applied to evaluate a subset of your current operations (e.g., inbound/domestic only). Note that in most cases performance metrics represent midpoints for the given ranking category range, rather than the precise value for a given carrier, as described above. If you have data specific to your carriers, select the **User Input** option (see below). Note that the **Shipper Carrier Average** option is not available for the commercial marine mode at this time.

Modal Average – This option will use an industry-average performance metric for the mode in question. Metric options include g/ton-mile and g/mile (or g/railcar-mile / g/barge-mile, as appropriate) and are currently available for truck, rail, multimodal, logistics, air (short and long-haul), and barge modes. The data sources and assumptions used to derive these values are discussed in the **Shipper Tool Technical Documentation**. You may want to use this option to investigate shifting freight to a transportation mode that you have not used previously, although we recommend that you use a more representative emission factor to analyze scenarios whenever possible.

Note: Modal averages for the multimodal selection are specific to intermodal truck/rail moves. Use the User Input option to provide performance metrics for other multimodal movements (e.g. truck/barge).

User Input – This option allows you to input performance metric estimates for any carrier mode, using alternative data sources. This option may prove particularly useful in those cases when you have access to carrier-specific performance estimates. You are encouraged to use this

option when you have access to an emissions factor that reflects the full emissions impact (e.g., including likely drayage emissions) and/or that best represents the fleet equipment and operational type that you are most likely to work with for your unique freight movement.

Note: The emission factors that automatically appear in the **Modal Shift Impacts** screen do not include all potential emissions impacts; for example, the factors do not include emissions associated with drayage (i.e., short-distance trips often required to move freight from one mode to another) or the operation of intermodal facilities.

- 3. Select the basis for performing the emission impact calculations, using either miles or ton-miles as inputs, by specifying the **Units** in the drop-down menu under the **Amounts** column. Mile inputs for truck, logistics, and multimodal modes correspond to truckload miles, barge-miles for barge modes, and railcar-miles for rail modes.
- 4. Once the **Units** are selected for the calculation, the screen will present the "Before" and "After" efficiency factors for the "From" and "To" modes for each of the four pollutants, in the table on the right side of the screen. If you specified the **User Input** option, enter the required efficiency factors in the empty white cells.
- 5. Next, specify the actual amount of freight to be shifted for both the "From" and "To" modes, in terms of miles or ton-miles, as appropriate. (Note that these two values can be different, since the point to point distance travelled is likely to be different across modes.) The corresponding emissions impact is then presented in tons per year for each pollutant. Emissions increases are shown as negative values. Note the mileage estimates under "Amounts" for railcar, barge and air freight need to be adjusted to reflect truckload-equivalents (on a volume basis) for accurate comparison with the truck mode. Refer to the **Shipper Tool Technical Documentation** for details.
- 6. If you selected the **User Input** option, provide a description of the data sources that you used to develop these estimates by selecting the **User Input Data Source** button.
- 7. Select the **HOME** button to return to the **Home** screen.

REVIEWING YOUR RESULTS

Now that you have identified your carriers and provided the required activity information, you
must examine your company's emission performance and mass emission estimates by selecting
the Review Your Results button under Step 7 on the Home screen. Carefully review the three
reports shown on the Emissions Summary, Carrier Performance, and Truck Carrier
Performance (SmartWay Category Detail) screens. These reports provide high level emissions
and performance summaries as well as detailed breakouts by mode and for specific carriers, as

well as by other category groupings. Review the results carefully for any anomalous results that may indicate possible carrier and/or activity data entry errors.

2. You will not be allowed to proceed through the Tool until you view each of these three screens. Once complete you can return to the **Home** screen.

SUBMITTING YOUR TOOL TO EPA

- 1. From the **Home** screen, select the **Generate a (.xml) data file** button which will open a new screen.
- 2. Select the checkbox to indicate you understand the terms of the SmartWay Partnership Agreement once again.
- 3. Specify if you are an existing SmartWay Partner. Select **No** if you did not have an approved tool submittal the prior year.
- 4. If you select **Yes**, you may enter your SmartWay ID number.
- 5. If you select **No**, specify how you initially heard about SmartWay, using the selections in the drop-down menu.
- 6. When ready, select NEXT to create a file with the following naming convention: Shipper_PartnerName_Year_V0.xml,⁸ where PartnerName is your partner name as entered in Step 1 on the Home screen, and Year indicates the year for which you are submitting data. For example, "Shipper_ABCompany_2017_V0.xml"
- 7. Specify the folder where you would like to save the .xml file, and save your file. Note that when you save your tool, it generates an .xlsm file in addition to the .xml file.
- 8. A screen will appear after you save your tool. Follow the instructions for submitting both your .xml and .xlsm files, if possible, to SmartWay. Note that the .xml file is approximately 10 times smaller than the .xlsm file.
- 9. Upon selecting **NEXT**, a screen will appear that allows you to close the Tool or return to the **Home** screen.
 - **NOTE**: DO NOT ZIP the .xlsm and .xml files. Send them to EPA as normal files attached to your e-mail. EPA security will not allow zipped files through the EPA firewall.

⁸ If you create the XML file multiple times the file name will increment each time (e.g., Shipper_ABCompany_2017_V1.XML for the second iteration, etc.

• NOTE: DO NOT CHANGE THE NAME OF THE XML OR XLS FILES.

Please visit <u>https://www.epa.gov/smartway/smartway-shipper-partner-tools-and-resources</u> for additional resources, including printable data collection worksheets, and technical documentation, for more in depth exploration of each section of the Shipper Tool.

Step 3 – Additional SmartWay Resources

After completing Steps 1 - 7 on the **Home** screen, EPA strongly encourages you to explore the optional sections of the Tool available at the bottom of the screen before completing your submission. Four options are provided in this section, including the following.

View Summary Data Reports – this button gives you access to 14 reports to help you understand your data and use it to make better performance decisions, including the new **Public Disclosure Report** containing Scope 3 emissions.

Feedback and Recruiting Assistance – On the **Suggestions** screen, you may respond to some or all of these questions in order to provide feedback regarding the various aspects of the SmartWay program. SmartWay values your feedback. Any information you provide will be used to improve the program, and will be kept confidential. Use the scroll bar to the right to display additional questions. On the **Recruiting Targets** screen, you may select up to 10 of your largest non-SmartWay carriers to help target companies for potential recruitment into the program.

Year-to-Year Comparison – The **Year-to-Year Comparison Report** allows the user to compare the company characteristics and activity values, as well as performance metrics for the current year with those of the prior year. This report is particularly helpful in identifying any changes that may have occurred since your last reporting period, determining trends in activity and performance over multiple years, and performing general quality assurance of the inputs used for your current Tool.

Visit the Partner Portal – You may select the **Visit the SmartWay Partner Portal** button which will open a web browser to the login page of the **EPA SmartWay Portal**. The portal provides access to a range of useful documents and functions including the partner registration document, the SmartWay Partner Logo, a sample press release, an online version of the feedback survey, and Awards information if applicable.

APPENDIX: WORKSHEETS FOR DATA COLLECTION

WORKSHEET #1: CONTACT INFORMATION

#1. Enter your Contact Information:

General Company Contact Information

Company Name								
Headquarters								
Mailing Address								
City		State/Province		Zip		Count	try	
Main Phone	Toll-free Number		Cell		Web Ad	dress		
Number			number					

Working Contact Information

Working Contact Name					
Working Contact Mailing					
Address					
City	State/Province		Zip	Country	
Working Contact Phone		Email			
Number		Address			

Executive Contact Information

Executive Contact Name					
Executive Contact					
Address					
City	State/Proving	ce 🛛	Zip	Country	
Executive Contact Phone		Email			
Number		Address			

Sustainability Contact Information

Sustainability Contact					
Name					
Sustainability Contact					
Address					
City	State/Province		Zip	Country	
Sustainability Contact		Email			
Number		Address			

Other Contact Information

Other Contact Name				
Other Contact Mailing Address				
City	State/Province		Zip	Country
Other Contact Phone		Email		
Number		Address		
Contact's role in program				

WORKSHEET #2: SHIPPER COMPANY CHARACTERIZATION

Complete this worksheet for <u>each shipper company</u> you will be submitting in the Shipper Tool.

#2: Define your Shipper Companies

Company Name (Partner Name followed by specific company name)

NAICS: _____ ____

Company Name (Partner Name followed by specific company name)

NAICS: _____ _____

Company Name (Partner Name followed by specific company name)

NAICS: _____ _____

Company Name (Partner Name followed by specific company name)

NAICS: _____ ____

WORKSHEET #3A: SELECT CARRIER(S) (PAGE 1 OF 2)

Complete the following for <u>each shipper company</u> you will be submitting in the Shipper Tool. Make multiple copies of the table below to enter all carriers used by the company if needed.

#3A: Identify your Shipper Carriers

Shipper Company Name _____

Total number of Non-SmartWay carriers used during current reporting year

Non-SmartWay Carrier modes (circle all that apply)

Truck Logistics Multimodal Barge Air

WORKSHEET #3A: SELECT CARRIER(S) (PAGE 2 OF 2)

List SmartWay Carriers

Carrier Name*	Mode ^	SmartWay Category**	SCAC^ ^	MCN^ ^	DO T #^^	Company Identifier^ ^	ID Code^ ^	Inbound/ Outbound / Internal^^	Domestic/ International^ ^	Internal Shipper Segments^ ^

* Exactly as it appears in SmartWay Carrier Data file

^ Truck, Rail, Logistics, Barge, Multimodal

** Truck categories include: Auto Carrier, Dray, Expedited, Flatbed, Heavy/Bulk, LTL Dry Van, Mixed, Moving, Package, Refrigerated, Specialized, Tanker, TL Dry Van

Note - Multimodal SmartWay Categories include: Surface, Surface-Air; Surface-Marine; Surface-Air-Marine

^^ Optional fields

WORKSHEET #3B: ACTIVITY DATA (PAGE 1 OF 2)

Complete the following for <u>each shipper company</u> you will be submitting in the Shipper Tool. Make multiple copies of the tables if needed to enter all carriers used by the company.

#3B: Enter Activity Data

Shipper Company Name:

Provide Data Source Description:

WORKSHEET #3B: ENTER ACTIVITY DATA (PAGE 2 OF 2)

Data Availability Option, Inventory Calculation Metric, Miles, Ton-Miles, and Average Payload

Carrier Name	Shipper Carrier (Y/N)	Data Availability Option (a-d)*	Ton-miles^^	Miles	Average Payload**

* Options include

a - Ton-miles and Total miles,

b - Ton-miles and Average Payload,

c - Total miles and Average Payload, and

d - Total miles only

** For Options b and c only

WORKSHEET #4: ENTER % SMARTWAY ALLOCATION DATA

Make multiple copies of this worksheet as needed to enter all carriers used by the company in the reporting year.

Shipper Company Name:

For each company, select the basis for allocating your % SmartWay Value across your carriers (circle one).

Ton-Miles Miles Custom Metric (% Spent, % Weight, % Packages, % Custom)

Describe Custom Metric (if applicable):

If using a Custom Metric, enter % allocation factors for each carrier, for % Spent, % Weight, % Packages, or % Custom allocations. Totals must sum to 100.

Carrier Name	% Allocation

WORKSHEET #5: ENTER MILE & WEIGHT IMPROVEMENTS DATA

Make multiple copies of this worksheet as needed to enter all shipper strategies used by the company.

Shipper Company Name:

Provide Name of Shipper Strategy _____

Select Activity Category (mark one):

- Miles Removed from the System
 - Distribution center relocation
 - o Retail sales relocation
 - Routing optimization
 - o Cube optimization
 - Larger vehicles and/or trailers
 - o Other (must specify)
- Weight Removed from System
 - o Product weight reduction
 - Package weight reduction
 - Vehicle weight reduction
 - o Other (must specify)

Specify Percent Improvement:

Mode	% Improvement
Air	
Truck	
Rail	
Logistics	
Multimodal	
Barge	

Describe Data Source/Methodology for % Improvement estimate(s):

WORKSHEET #6: ENTER MODAL SHIFT IMPACTS DATA

Make multiple copies of this worksheet as needed to enter all modal shifts used by the company.

Shipper Company Name:

Select "From" Mode (circle one): Truck Rail Logistics Multin	nodal Air	Barge		
Select "To" Mode (circle one): Truck Rail Logistics Multin	modal Air (sł	nort or long-haul) Barge	Marine – OGV	
Select Emission Factor Source – "From" Mode (circle one): Shipper Carrier's Average Modal (industry) Average User Input				
Select Emission Factor Source – "To" Mode (circle one): Shipper Carrier's Average Modal (industry) Average User Input				
Select Activity Units (circle one): Miles Ton-Miles				
Specify Activity Amount – "From" Mode:				
Specify Activity Amount – "To" Mode:				